



Tube positioning plate

# Eccentric Flaring Tool



Avoid leaks, make the perfect flare the easiest way with the Tube Positioning Plate – the plate ensures the tube is set at the correct position

- Hard plastic carry case

Set options	Part No.
7 Sizes: 3/16" 1/4", 5/16", 3/8", 1/2", 5/8", 3/4"	JAV-1024
7 Sizes: 6, 8, 10, 12, 15, 16, 18mm	JAV-1185

# Flare Size Gauge

Designed to measure all flares to offer 100% seal tightness against all flare fittings, a must for every toolbox.

Description	Part No.
Flare Size Gauge	JAV-1022



Information correct at time of going to press.