

# Eccentric flaring



## Eccentric flaring tool

### JAV-1024 / JAV-1185

Avoid leaks, make the perfect flare the easiest way with the Tube Positioning Plate – the plate ensures the tube is set at the correct position. Hard plastic carry case.



Tube positioning plate

Size O.D.	Part No.
7 sizes: 3/16" 1/4", 5/16", 3/8", 1/2", 5/8", 3/4"	<b>JAV-1024</b>
7 sizes: 6, 8, 10, 12, 15, 16, 18 mm	<b>JAV-1185</b>

mm : coming soon

## Flare size gauge

### JAV-1022

Designed to measure all flares to offer 100% seal tightness against all flare fittings, a must for every toolbox.

